


Installationsanleitung PRIME-ODF-Gestell
Installation guide PRIME-ODF-Cabinet
Instructions de montage PRIME-ODF-Cabinet



Standard / Flat Pack



B x T x H / W x D x H
900 x 300 x 2200 mm
900 x 300 x 1650 mm

021.5279

Standard / Flat Pack



B x T x H / W x D x H
300 x 300 x 2200 mm

022.0005.1

**Wandgestell / Wall cabinet
Standard**



B x T x H / W x D x H
900 x 300 x 1200 mm

021.5277





**Wandgestell / Wall cabinet
Standard**




B x T x H / W x D x H
900 x 300 x 700 mm






021.5278

B - Flat Pack Gestell / Flat Pack Cabinet




C - Gestell Montage / Cabinet mounting







C8 Bodenbefestigung / Floor mounting





C9 Wandbefestigung / Wall mounting



C10 Gestellverbindung / Cabinet connection










D


Montage links / Mounting left







Montage rechts / Mounting right





Montage mitte / Mounting center





E - Gestell Kabeleinführung oben / Cable insertion cabinet top









F - Kabel und Faseraufleitung seitlich / Cable and fiber distribution lateral






G - Kabel und Faseraufteilung unten / Cable and fiber distribution below






H - Kabelhalter seitlich / Cable holder lateral



I - Erdungskonzept/ Grounding concept



Mehr Details finden Sie in den separaten Installationsanleitungen:

PRIME-3HE-Sub-rack
PRIME- $\frac{3}{4}$ HE-FTU, FBU, FSU, FOU



More detail can be found in the separate installation guides:

PRIME-3U-Sub-rack
PRIME- $\frac{3}{4}$ U-FTU, FBU, FSU, FOU

Headquarters

Switzerland

Reichle & De-Massari AG
Binzstrasse 32
CHE-8620 Wetzikon
Telephone HQ +41 (0)44 933 81 11
Telefax HQ +41 (0)44 930 49 41
E-Mail hq@rdm.com

www.rdm.com

R&M

Please note:

This guide shows the best practices for installation **ONLY**. R&M expressly disclaims all liability for any damage to material, equipment, and for any injury or death. Legal health and safety regulations should have priority over best practices as shown in this guide. R&M does not guarantee this guide to be free of errors. Products included may vary from products shown. Please exercise caution.