



Installationsanleitung ZOONA Muffe STP4 (Lange Version)
Installation guide ZOONA Closure STP4 (Long version)






A - Muffe öffnen / Open closure



B - Loop installieren / Install loop





B11 Schlitten entfernen / Remove slide unit



B12




B13




B14






B15 Zentralelement / Central member




B16 Zentralelement fixieren / Secure central member






B23 Loop einführen / Insert loop




B24




B25 Dichtungen anziehen / Compress seals



B26



B27 Loop einlegen / Insert loop



B28 Loop fixieren / Secure loop



B29 Bündelader nach vorne führen / Guide loose tube to the front



B30 Bündelader absetzen / Strip loose tube









B31 Bündelader sichern / Secure loose tube








B32 Fasern einlegen / Insert fibers




C - Kabel vorbereiten / Prepare cable






D - Kabel einführen / Insert cable


D1 Blindstopfen entfernen / Remove dummy plug



D3 Position Kabeleinführung / Position cable entry



D4 Bündelader absetzen und sichern / Strip loose tube and secure







D5 Fasern einlegen / Insert fibers



E - Splittermontage / Mounting splitter

E1 Maximale Splitterbelegung / Maximum splitter occupancy



F - Muffe schliessen / Close closure

F1 Dichtung kontrollieren / Check seal



F2



F3




F4





F5 Optional / Optional





G - Wandbefestigung / Wall mounting



H- Zubehör (Mastbefestigung) / Accessories (Pole fixing bracket)



I - Zubehör (Kabelhalter) / Accessories (Cable support)



Headquarters

Switzerland

Reichle & De-Massari AG

Binzstrasse 32

CHE-8620 Wetzikon

Telephone HQ +41 (0)44 933 81 11

Telefax HQ +41 (0)44 930 49 41

E-Mail hq@rdm.com

www.rdm.com

R&M

Please note:

This guide shows the best practices for installation **ONLY**. R&M expressly disclaims all liability for any damage to material, equipment, and for any injury or death. Legal health and safety regulations should have priority over best practices as shown in this guide. R&M does not guarantee this guide to be free of errors. Products included may vary from products shown. Please exercise caution.